Leland Legacy Quick Guide

Terms »

Star button ✷
- Scrolls through run time data and Setup options

Up and down arrow buttons ▲▼
- Toggle between display choices and increase or decrease sampling parameters in Setup

Button sequence
▼ ✷ = press buttons individually
[▲▼] = press simultaneously
✷▲▼✷ = security code, always press in sequence

Security code ✷▲▼✷
- Prevents unauthorized changes to the pump's sampling program

Programming Sequences »

- **To activate pump (e.g., to change pump from Sleep to Hold):**
  Press any button.

- **To change pump from Hold to Run or Run to Hold:**
  Press [▲▼].

- **To reset accumulated data:**
  Press [▲▼], then ✷▲▼✷. Press ✷ until *CLr* displays and then press [▲▼]; press ✷ until *End* displays and then press [▲▼].

- **To set pump flow rate:**
  Press [▲▼], then ✷▲▼✷. Flow rate and SET flash. Press ▲ or ▼ to change flow rate. Press ✷ until *End* appears and then press [▲▼] to save setting and place pump in Hold.

- **To verify flow rate with standard flowmeter:**
  Press [▲▼], then ✷▲▼✷. Flow rate and SET flash. Press ▲ or ▼ to change flow rate. Press ✷ once. *ADJ* displays. Press ▲ or ▼ until desired flow rate is indicated on flowmeter. When finished, press ✷ until *End* displays and then press [▲▼] to save new setting and place pump in *Hold. For CalChek Single-point Flow Verification and Full Calibration, see operating instructions.*

- **To change temperature scale from F to C or C to F:**
  Press [▲▼], then ✷▲▼✷. Press ✷ until temperature displays. Press ▲ or ▼ to switch units; press ✷ until *End* displays and then press [▲▼] to save new setting.

- **To change atmospheric pressure scale (mm, mb, In):**
  Press [▲▼], then ✷▲▼✷. Press ✷ until pressure displays and then press ▲ or ▼ to switch units; press ✷ until *End* displays and then press [▲▼] to save new setting.

- **To change time scale (12 Hr/24 Hr/Dela):**
  Press [▲▼], then ✷▲▼✷. Press ✷ until 12 Hr, 24 Hr, or Dela displays and then press ▲ or ▼ to switch units; press ✷ until *End* displays and then press [▲▼] to save new setting. *To set delayed start (Dela), see operating instructions.*

- **To change clock:**
  Press [▲▼], then ✷▲▼✷. Press ✷ until clock displays and then press ▲ or ▼ to change flashing hour; press ✷ to move to minutes and ▲ or ▼ to change setting. Press ✷ until *End* displays and then press [▲▼] to save new setting.

- **To change the sampling time function:**
  Press [▲▼], then ✷▲▼✷. Press ✷ until *ST L/min* displays and then press ▲ to change flashing digit; press ✷ until *End* displays and then press [▲▼] to save new setting. To delete, follow above steps and press ▼ until 0 appears. Exit Setup.

Note: When in Setup, choosing Esc instead of End will exit Setup without saving new settings.

SKC Inc., 863 Valley View Road, Eighty Four, PA 15330 • www.skcinc.com

Form 37138 Rev 251210