Pocket Pump TOUCH
Installation/Operation Caution Guide

Markings

SKC Pocket Pump TOUCH 220-1000TC SN YY9999
Class I, Groups A, B, C, D; Class II, Groups E, F, G; Class III, T4;
Class I, Zone 0, Group IIC T4; Ex ia -20°C ≤ T_a ≤ 45°C
Ex II 1G Ex ia IIC T4 Ga ; IECEx UL 16.0113, DEMKO 16ATEX 1600
UL22UKEX2584
CE 0539 UKCA 0843

Warnings and Cautions

Warnings:

- Substitution of components may impair intrinsic safety.
- To prevent ignition of hazardous atmosphere, do not charge/change batteries in hazardous areas.
- Use only SKC charger P/N 220-300.
- Maximum charge input voltage U_m=5.5V (for Intrinsic Safety purposes only).

Avertissements:

- La substitution de composants peut compromettre la Sécurité Intrinsèque.
- Afin de prévenir l'inflammation d'atmosphères dangereuses, ne pas charger ni remplacer la batterie dans un emplacement dangereux.
- Utiliser uniquement les berceaux de charge SKC, numéro de pièce 220-300.
- Tension d'entrée de charge maximale U_m=5.5V (uniquement à des fins de Sécurité Intrinsèque).

Cautions:

- The battery used in this device may present a risk of fire or explosion when heated above 212 F (100 C) or incinerated.
- The battery packs were evaluated based on the following parameters and shall not be exceeded:
  - Maximum charging voltage: 4.2 Vdc
  - Maximum charging current: 400 mA
- Replace battery with SKC Unlisted Component Battery Pack Model P76303 or P76303A only. Use of another battery may present a risk of fire or explosion.

Mises en garde:

- La batterie utilisée dans cet appareil peut présenter un risque d'incendie ou d'explosion lorsqu'elle est chauffée à plus de 212 °F (100 °C) ou incinérée.
- Les blocs-batteries ont été évalués selon les paramètres suivants et ne doivent pas être dépassés:
  - Tension maximale de charge: 4,2 Vcc
  - Courant maximal de charge : 400 mA
- Remplacer la batterie uniquement par le bloc-batterie composant non répertorié SKC, modèle P76303 ou P76303A. L'utilisation d'une autre batterie peut présenter un risque d'incendie ou d'explosion.

Replacing the Battery

1. Turn pump off using on/off button.
2. Use 1.5-mm hex drive to loosen the two screws on the bottom of the battery pack.
3. To remove battery pack, lift it up against belt clip. Once clear of case, pull away from pump case.
4. To install battery, align it with bottom of pump case and push it up against belt clip until battery pack presses easily into place. Tighten the two battery screws.

Remplacement de la Batterie

1. Éteindre la pompe à l'aide du commutateur Marche/Arrêt.
2. À l'aide d'une clé hexagonale (clé Allen) de 1,5 mm, desserrer les deux vis situées au bas du bloc-batterie.
3. Pour retirer le bloc-batterie, le soulever vers l'agrafe de ceinture. Une fois dégagé du boîtier, tirer le bloc-batterie pour l'éloigner du boîtier de la pompe.
4. Pour installer la batterie, l'aligner avec la partie inférieure du boîtier de la pompe et la pousser vers l'agrafe de ceinture jusqu'à ce que le bloc-batterie s'insère facilement en place. Serrer les deux vis du bloc-batterie.