



### Surface SWYPE for Aromatic Isocyanates Cat. No. 769-1022

1. Lightly spray the area or item (e.g., workbench, tool, control knob) with Developing Solution for Isocyanates Cat. No. 769-1062.
2. Wait at least 30 seconds and then wipe with a Surface SWYPE pad.
3. Allow 3 minutes for the color to develop on the pad. A red-orange color is specific for isocyanates.

#### **SKC Limited Warranty and Return Policy**

SKC products are subject to the SKC Limited Warranty and Return Policy, which provides SKC's sole liability and the buyer's exclusive remedy. To view the complete SKC Limited Warranty and Return Policy, go to [skcinc.com/warranty](http://skcinc.com/warranty).