



Surface SWYPE for Phenols Cat. No. 769-1027

1. Lightly spray the area or item (e.g., workbench, tool, control knob) with Developing Solution for Phenols Cat. No. 769-1067.
2. Wait at least 30 seconds and then wipe with a Surface SWYPE pad.
3. Allow 3 minutes for the color to develop on the pad. A red color is specific for phenol.

SKC Limited Warranty and Return Policy

SKC products are subject to the SKC Limited Warranty and Return Policy, which provides SKC's sole liability and the buyer's exclusive remedy. To view the complete SKC Limited Warranty and Return Policy, go to skcinc.com/warranty.