



### Surface SWYPE for o-Phthalaldehyde Cat. No. 769-1029

1. Lightly spray the area or item (e.g., workbench, tool, control knob) with Cleaning/Developing Solution for o-Phthalaldehyde Cat. No. 769-1069 or 769-1055.
2. Wait at least 30 seconds and then wipe with a Surface SWYPE pad.
3. Allow 15 minutes for the color to develop on the pad. o-Phthalaldehyde will produce the following color:
  - Reddish

*Note: Although the color is stable, it is recommended that you read the color after 15 minutes.*

#### **SKC Limited Warranty and Return Policy**

SKC products are subject to the SKC Limited Warranty and Return Policy, which provides SKC's sole liability and the buyer's exclusive remedy. To view the complete SKC Limited Warranty and Return Policy, go to [skcinc.com/warranty](http://skcinc.com/warranty).