Build a single-tube low flow sampling train in three easy steps: Step 1. Select a pump Step 2. Select the pump-specific tube holder Step 3. Select a protective tube cover (based on the sorbent tube size from the relevant sorbent tube page). Note: Pocket Pump TOUCH tube holders are non-adjustable and are supplied with a tube cover - select the appropriate model based on size of sorbent tube used. Step 1 Step 3 Step 2 **Pumps Tube Holders Tube Covers Only** All-in-One Low Flow/Single Adjustable AirChek 52/Sidekick **A** (6-mm OD x 70-mm L) AirChek XR5000 Tube Holder with built-in CPC Cat. No. 224-29A AirChek TOUCH **AirChek Connect** Cat. No. 224-27 AirChek Essential+ AirChek Essential See convenient Low Flow **B** (7 or 8-mm OD x 110-mm L) **AirLite** Adapter Kit below. Cat. No. 224-29B AirChek 3000 SKC **C** (10-mm OD x 150-mm L) Cat. No. 224-29C Universal Series Adjustable Low Flow Tube Holder Cat. No. 224-26-01 **D** (10-mm OD x 220-mm L) Cat. No. 224-29D Match the letter indicated in the Tube Cover column of the table for the relevant Sorbent Tube to the letter above.

