



863 Valley View Rd, Eighty Four, PA 15330
724-941-9701
skcinc.com

Skin SWYPE for Nickel **Cat. No. 769-1038** **Operating Instructions**

Limited shelf-life: Check expiration date on packaging.

1. Wipe the skin with the cloth portion of the Skin SWYPE pad.
2. Pour $\frac{1}{4}$ inch of Cleaning/Developing Solution for Nickel Cat. No. 769-1068 or 769-1054 into the small cup provided.
3. Put the Skin SWYPE pad in the cup, cloth end down and color detection strip up. The developing solution will wick up to the color detection strip and a color change will occur if contamination is present.
4. Allow 3 minutes for color to develop on the strip. Nickel will produce the following color:
 - Pink

Note: Although the color is stable, it is recommended that you read the color after 3 minutes.

SKC Limited Warranty and Return Policy

SKC products are subject to the SKC Limited Warranty and Return Policy, which provides SKC's sole liability and the buyer's exclusive remedy. To view the complete SKC Limited Warranty and Return Policy, go to skcinc.com/warranty.