



863 Valley View Rd, Eighty Four, PA 15330  
724-941-9701  
skcinc.com

## Skin SWYPE for o-Phthalaldehyde Cat. No. 769-1039 Operating Instructions

**Limited shelf-life:** *Check expiration date on packaging.*

1. Wipe the skin with the cloth portion of the Skin SWYPE pad.
2. Pour ¼ inch of Cleaning/Developing Solution for o-Phthalaldehyde Cat. No. 769-1069 or 769-1055 into the small cup provided.
3. Put the Skin SWYPE pad in the cup, cloth end down and color detection strip up. The developing solution will wick up to the color detection strip and a color change will occur if contamination is present.
4. Allow 10 to 15 minutes for color to develop on the strip. o-Phthalaldehyde will produce the following color:
  - Red

**Note:** *Although the color is stable, it is recommended that you read the color after 15 minutes.*

### **SKC Limited Warranty and Return Policy**

SKC products are subject to the SKC Limited Warranty and Return Policy, which provides SKC's sole liability and the buyer's exclusive remedy. To view the complete SKC Limited Warranty and Return Policy, go to [skcinc.com/warranty](http://skcinc.com/warranty).

Form 37566 Rev 241106