



863 Valley View Rd, Eighty Four, PA 15330
724-941-9701
skcinc.com

PERMEA-TEC Sensor for Phenols **Cat. No. 769-3007** **Operating Instructions**

Limited shelf-life: Check expiration date on packaging.

The PERMEA-TEC Sensor colorimetric screening method determines the effectiveness of chemical-protective gloves and clothing under actual use conditions. CLI's microencapsulation detection indicator changes color, indicating permeation for many common phenols. Results enable professionals to select the gloves/clothing best suited for protection, acceptance, and cost-effectiveness.

PERMEA-TEC sensors are adhered to a worker's skin at points of greatest contact and abrasion before gloving or covering and are observed for color change at time intervals.

Instructions for Use

To determine a user-safe time period for the particular glove, double gloving is recommended.

1. Affix PERMEA-TEC sensors to the thumb, middle finger, and palm on the outside of the glove currently being worn. Place the glove to be evaluated over the first glove.
2. After one hour, remove the outside glove and the underlying PERMEA-TEC sensors.
3. Develop the pad by spraying it twice with Phenol Devel-

- oping Solution Cat. No. 769-1067. A positive indication of breakthrough results in a color change to red.
4. If no breakthrough is indicated, apply fresh PERMEA-TEC sensors and continue to wear the outside glove for another hour. Follow Steps 2 and 3 to determine if breakthrough has occurred.
 5. Repeat Steps 3 and 4 to determine a user-safe time period for gloves.

Other PERMEA-TEC sensors are available for:

Aromatic Amines:	MDA, aniline, o-Toluidine, methylene-bis(2-chloroaniline) (MOCA)
Aromatic Isocyanates:	TDI, MDI
Aliphatic Amines:	N,N-dimethylcyclohexylamine, triethanolamine, diethanolamine, and triethylenediamine
Aliphatic Isocyanates:	HDI, HMDI
Acid/Base:	HCl, HF, H ₂ SO ₄ , and NH ₃
Solvents	

SKC Limited Warranty and Return Policy

SKC products are subject to the SKC Limited Warranty and Return Policy, which provides SKC's sole liability and the buyer's exclusive remedy. To view the complete SKC Limited Warranty and Return Policy, go to skcinc.com/warranty.