



863 Valley View Rd, Eighty Four, PA 15330
724-941-9701
skcinc.com

DECONTamination Solution for Hexavalent Chromium Cat. No. 769-1074 Operating Instructions

Limited shelf-life: Check expiration date on packaging.

Cleaning/Decontamination

1. Wet area thoroughly with DECONTamination Solution for Hexavalent Chromium. Use an abrasive pad if necessary to enhance penetration.
2. Allow solution to react for at least 5 minutes. Rinse with water.
3. Recheck the area with Surface SWYPE for Hexavalent Chromium Cat. No. 769-1030 and Cleaning/Developing Solution for Hexavalent Chromium Cat. No. 769-1070 to verify decontamination is complete. If contamination is still present, repeat Steps 1 and 2.
4. To decontaminate tools, soak them in DECONTamination solution for at least 5 minutes and rinse with water. Recheck with Surface SWYPE to verify decontamination is complete.

SKC Limited Warranty and Return Policy

SKC products are subject to the SKC Limited Warranty and Return Policy, which provides SKC's sole liability and the buyer's exclusive remedy. To view the complete SKC Limited Warranty and Return Policy, go to skcinc.com/warranty.

Form 40163 Rev 241111